

 HARDWARE								
В								
c	М							
	Р		Q					
F	R		s					
G								
_	ID	PART #	DESCRIPTION					
	В	300-565	Drop In Nut					
	C	300-518	1/4-20 x 3/8" Button Head Socket Screw					
	D	301-000	5/16 x 3/4" Countersink Socket Screw					
J	E F	300-485	1/4-20 x 1/2" Button Head Socket Screw					
	G	301-055 301-730	3/8 x 2" Alligator Wall Anchors 5/16 x 2.5" Lag Bolt					
	H	303-505	1/4-20 x 3/4" Set Screw					
	I	300-465	1/4-20 x 3/4" Head Socket Screw					
K	J	302-310	10-32 x 5/8" Button Head Socket Screw					
	K L	301-695 303-525	M8 x 16 mm Pan Phillips Head Screw 5/16-18 x 1.50" Head Socket Screw					
	M	303-525 300-468	1/4" Flat Washer					
	N	300-560	1/4-20 Flat Nut					
	0	303-855	Universal Wall Bracket					
	P	301-745	Hollow Wall Anchors					
	Q	300-470	5/16" Flat Washer					
	R S	301-265 300-835	1/4-20 - JCN Universal Shelf Peg					
			- · · · · · · · · · · · · · · · · · · ·					

TOOLS INCLUDED

PART #	DESCRIPTION

P-400-030	Driver Bit 1/4" Hex Key
400-030	1/4" Hex Key
400-070	1/8" Hex Key
400-080	5/32" Hex Key
400-058	3/16" Hex Key- Short Arm
400-035	Leveler Wrench
301-240	1"x 2" Double Sided Tape

TOOLS NEEDED

Drill Driver #2 Phillips Head Screw Driver 1/2 Drill Bit for Standard Installation 3/16" Drill Bit for Wood Stud Installation 3/8" Drill Bit for Masonry Installation Pencil Tape Measure Level

WARNINGS

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING THIS FURNISHING

MARNING! Failure to comply with these instructions may result in accident involving serious personal injury. Failing to follow these instructions can result in the product being damaged or being destroyed or voiding of the warranty.

WARNING! For use with video monitors weighing **175lbs (80kg)** or less. Use with heavier televisions may result in instability causing tip over resulting in death or serious injury.

CAUTION!

- Close supervision is necessary when this furnishing is used by or near children, invalids, or disabled persons
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- Do not use outdoors
- For Commercial Use Only

Weight Capacities: Max Load: D1/337AM1 - 175 lbs (80kg)

***** SAVE THESE INSTRUCTIONS *****

Accessories and Spare Parts

Please contact Salamander Designs 860.761.9500 or www.salamanderdesigns.com




Determine if Extension Wings are Required to Mount Your Display

Measure the mounting pattern on your display:

200 x 200 to 600 x 400 Use Only Display Brackets


600 x 400 to 800 x 500 Use Display Brackets with Extension Wings


B



Assemble Extension Wings if Required

Extension wings are fastened to display brackets using the 3 flat head screws, washers and lock nuts provided in the PL100 Mount Kit prior to mounting your display.





1. INSTALL DISPLAY BRACKETS

Attach Brackets to Display


Fasten the brackets using fasteners (length and size recommended by the display manufacturer). *Using improper screw length can damage the display.*

NOTE:

An assortment of screws and optional spacers have been provided in the PL100 Kit.

Optional Spacers are provided for additional clearance between the mount and the Display if necessary.

M8 16mm screws are supplied for use with Microsoft Surface Hub.



2. ADJUSTING MOUNT

Determine Vertical Position of Mount

Measure from the bottom of display to center of display mount bracket.

Determine Horizontal Position of Mount


Measure the length of the display and divide by 2 to get the horizontal mount center.

NOTE:

Α

В

If a space between the two displays is required, add half of the width of the space to this dimension.



2. ADJUSTING MOUNT



Determine Current Vertical Position of Mount - This will provide bottom of screen to floor dimension for the current position of the mount.


Measure from the floor or top of cabinet to the current center of the Mount Plate installed and subtract the vertical dimension determined in step 2A. The difference is the amount of adjustment required.



Determine Current Horizontal Position of Mount

Measure from the center line of the cabinet to the center of the Mount Plate and subtract the horizontal dimension determined in step 2B. The difference is the amount of adjustment required.

Follow steps 2E thru 2I if vertical and/or horizontal adjustments are needed.




2. ADJUSTING MOUNT


Vertical Mount Adjustment

Vertical adjustment is incrementally made by using the holes spaced 2" on the vertical mounting extrusions. If both vertical and horizontal adjustments are need please read both 2E thru 2I prior to making adjustments. Fastening points are shared.

Loosen Mount Plate and slide left or right to gain access to the fasteners of the horizontal mounting extrusions.



Loosen bolts fastening the horizontal mounting extrusions to vertical mounting extrusions. The flat nuts at the back of the vertical mounting extrusions will drop and need to be repositioned.



If vertical adjustment are necessary reposition the horizontal mounting extrusions with the fasteners in place and refasten to the vertical mounting extrusions. Level the wall bracket while retightening move to step 2F if horizontal adjustments are needed.


2. ADJUSTING MOUNT



Horizontal Mount Adjustment

Relocate the bolt positions on the vertical mounting extrusions to provide 2" incremental adjustments.

NOTE: The center line of the Display should never be positioned further than the indication shown



** The Diagram above show the horizontal mounting extrusions without mount plates for visual clarification **

Re-fasten assembly while re-leveling mount plates.

NOTE: It is important to Display alignment that brackets are level and aligned. A long straight edge or string can help to measure.

3. CAMERA SHELF (OPTION)




Install Mount

Loosely assemble Screws (C), Washers (M) and Drop-In Nuts (B) though Bracket (O).

Affix Bracket to top of the horizontal mounting post by sliding Drop-In Nuts (B) into slots.

Adjust bracket to desired location an tighten with provided Hex Key.

Verify that Drop-In Nuts catch extrusion.





Install Mount

B

Insert 2 Flat Nuts (N) into Camera Mounting post.

Insert Screw (E) and Washer (M) through the Bracket and tighten with Hex Key.






С

Μ

В


C





5. LEVEL CABINET & MARK WALL

Prior to fastening to wall, it is important to level the cabinet with the floor by verifying that feet are properly adjusted.




6. INSTALL WALL FASTENERS (MOST APPLICATIONS)

Install wall fasteners to marked location on wall & fasten cabinet.

NOTE: Alternate fasteners (G & M) provided for wood studs.




Drill 1/2" diameter hole. Hold metal channel flat alongside plastic straps and slide channel through hole.



/	-	`
	D	1
	D	
		/
	\sim	


Hold ends of straps between thumb and forefinger and pull toward you until channel rests flush behind wall. Slide plastic cap along straps with either hand with flange of cap is flush with wall.





Α

Snap straps at wall by pushing side to side, snapping of straps level with flange of cap.



/		
	\sim	


Move cabinet to wall and attach bracket. Insert bolt through Bracket and tighten until snug against wall.


7. INSTALL WALL FASTENERS (ALTERNATE)

WOOD: Locate two framing studs using a stud finder device.

MASONRY: Place brackets in desired location.

B) Use a 3/16" [5mm] drill bit and drill holes 2.5" [64mm] deep.









Insert wall anchors (F) into hole.

Place cabinet in place and fasten with washers (M) and Lag Bolts (G).






9. INSTALL SHELVES

NOTE: Shelf pegs can be re-positioned if desired.

- A. Place shelves on pegs.
- B. Install shelf stops in front or back of shelf as desired.
- **C.** Shelf placement can be adjusted if necessary to either pre-drilled. locations or any location using Drop-In Nuts (B) supplied.
- D. Install accessories (IR Repeater Kit, Power Conditioner, etc) and place components.




10. INSTALL DISPLAY TO MOUNT


Lift display and place on Plano mounting bracket.

NOTE:


Be sure that lip of screen brackets are aligned with the mounting bracket. Failure to do so may result in injury or damage to product.




Pull on black cord to unlock click fasteners and hook tv brackets onto wall bracket from top.



Center tv brackets on wall bracket and push black click fasteners Up into lock position.




Install pad lock.




ADJUSTMENT TIPS

MODESTY PANEL *Removing and Re-Installing*

NOTE: Be sure bottom of modesty panel is flush to cabinets top.





3U VERTICAL RACK (OPTION)



Remove

Loosen screws on both sides. Then tilt rack until the hook is free and lift up until the rack is free from bottom screw.







Re-Install Slide the slotted ends of the rack over the bottom screw and hook the top screw as shown.




) Tighten with provided Hex Key.

ADJUSTMENT TIPS

DOORS

NOTE: It is important that cabinet is level before adjusting doors, see step 5.





LIMITED WARRANTY FOR COMMERCIAL VIDEO DISPLAY STANDS AND MOUNTS

Salamander is proud to stand behind our products with industry-leading warranties. Should you ever encounter any problem with your Salamander product, let us know. We are here to make it right. 1.860.761.9500

Full warranty including limitations and warranty claim information may be found at www.salamanderdesigns.com/customer-service/warranty

Made in USA